





## Parts List for DHS790AT2 Type 20

Item Number	Part Number	Description	Qty Required
1	N451835	ARM ASSEMBLY	1
2	N459234	BELT COVER	1
3	330045-14	SCREW, TAPTITE	7
4	146751-00	SHAFT,PIVOT	1
5	146732-00	SPACER	2
6	N039404	TORSION SPRING	1
7	150075-00	SCREW,SET	2
8	N377514	BUSHING	2
9	387130-00	LOCKING PIN	1
10	034158-00	O RING	1
11	N058304	REAR GUARD	1
12	330045-23	SCREW,TAPTITE	8
13	153603-01	PAWL	1
14	153639-00	SCREW,SHOULDER	5
15	153655-00	WASHER,WAVY	2
16	N185664	ADJUSTMENT SCREW	1
17	150718-00	NUT,WING	1
18	N439376	WORK LIGHT	1
20	618198-00	SCREW	1
23	N436564	BOLT ASSY	1
24	151962-01	CLAMP,OUTER	1
25	152636-00	ADAPTOR,BLADE	1
26	644999-00	WASHER, INNER BLADE	1
28	N141275	SPINDLE & GEAR	1
29	330003-66	BEARING, BALL	1
30	391616-00	NEEDLE BEARING	1
31	N139533	GEAR-INTER.	1

## Parts List for DHS790AT2 Type 20

Item Number	Part Number	Description	Qty Required
32	605040-20	BALL BEARING	1
33	605040-33	BEARING	1
34	N203541	PINION SHAFT ASSY	1
35	153752-00	RING,RET.EXT	2
36	618244-00	RETAINING PLATE	1
37	330045-49	SCREW	11
38	391310-00	BEARING PLATE	1
40	N004511	DRIVEN PULLEY	1
44	N268679	GEAR CASE COVER ASSY.	1
45	391315-00	GASKET	1
47	153555-00	BELT	1
49	153561-00	PIN,LOCK	1
50	448176-00	SPRING	1
51	393071-00	RET. PLATE	1
52	330045-45	SCREW	8
53	153559-00	WASHER,FELT	1
56	146740-00	SLEEVE,FLANGED	2
57	394589-01	SCREW	2
60	330045-15	SCREW	12
61	N142121	DUST DUCT ASSY.	1
62	N080677	LOCK KNOB	1
68	N058308	BEVEL POINTER	1
69	N058309	BEVEL POINTER	1
70	N080199	KNOB	1
72	060325-01	RING	1
74	330045-06	SCREW	7
76	N090294	BEVEL SCALE	1

## Parts List for DHS790AT2 Type 20

Item Number	Part Number	Description	Qty Required
80	N043045	PAWL	2
83	N049689	STOP PLATE	1
85	N051519	STOP PLATE	1
91	330015-03	NUT,HEX	1
92	N058312	SCREW	2
93	N450450	BASE ASSEMBLY	1
94	618192-00	WEAR PLATE	1
95	N057391	KERF PLATE	2
96	N450345	TABLE ASM	1
97	N401778	COVER	1
99	049787-00	O RING	1
100	N058318	SCREW	1
101	N044739	LOCK NUT	1
102	153792-00	WASHER	4
103	N059784	DETENT PLATE	1
104	604410-00	SCREW	2
105	391358-01	WRENCH HOLDER	1
106	608563-02	WRENCH	1
107	N057963	POINTER	1
108	N050755	ACTUATOR	1
109	N066280	CLAMP PLATE	2
110	622396-00	SHAFT	1
111	622395-00	LEVER	1
112	N472413	DETENT	1
113	618176-00	SPRING	1
114	093128-00	NEEDLE BEARING	2
115	618254-00	RETAINER	1

## Parts List for DHS790AT2 Type 20

Item Number	Part Number	Description	Qty Required
116	N082785	LEVER	1
117	N057386	PIN	1
118	624460-00	PIVOT PIN	1
119	624461-00	SLEEVE	1
120	618186-00	ROD	1
121	618185-00	BLOCK	1
122	385915-03	SHOULDER SCREW	1
123	618253-00	SPRING	1
124	N434092	HANDLE SET	1
125	330045-18	SCREW	4
126	330019-32	SCREW	3
128	N447769	SWITCH	1
129	N458834	SCREW	4
130	330045-23	SCREW,TAPTITE	1
131	330019-12	SCREW	2
133	N083060	HANDLE	1
134	330019-22	SCREW	1
135	398443-00	CABLE CLAMP	1
137	N030322	COVER	1
138	N450332	FENCE	1
139	N450335	LEFT FENCE	1
140	N450342	RIGHT FENCE	1
141	N142125	BEVEL KNOB	2
142	098105-03	SCREW	4
143	N473903	MOTOR ASSEMBLY	1
144	N448791	DUST COVER	1
145	N480342	SCREW, SHOULDER	1

## Parts List for DHS790AT2 Type 20

Item Number	Part Number	Description	Qty Required
146	N443878	JUMPER	1
147	N443879	JUMPER	1
148	N449481	HEYCO BUSHING	1
149	048822-00	HEYCO BUSHING	1
150	N004510	DRIVE PULLEY	1
151	N426940	BASE HOUSING	1
152	323924-08	SCREW,M3.5 X 12	4
153	N426941	HOUSING	1
154	N449474	SCREW-THD.FORM	1
155	N461735	SPRING	2
157	N426942	END HOUSING	1
158	330019-16	SCREW	10
160	N457628	RATING LABEL	1
170	N450353	SUPPORT HOUSING	1
171	603390-00	SCREW	8
172	397118-00	GUIDE	2
173	153576-04	SET SCREW	1
174	613497-00	SLUG	1
175	N058314	SHOULDER SCREW	4
177	N051244	BUMPER	2
178	659919-00	SPRING,CONICAL	1
179	612008-00	SCREW	1
180	N459410	BEVEL HANDLE	1
181	330016-04	WASHER	1
183	N095579	STOP LEVER	1
184	167785-00	SPRING	1
185	N041865	STOP PIN	1

## Parts List for DHS790AT2 Type 20

Item Number	Part Number	Description	Qty Required
187	153797-00	SCREW	1
188	N058315	SHOULDER SCREW	2
189	385946-00	WASHER,SPRING	4
190	N043046	PAWL	2
192	153797-04	SCREW	2
194	N058306	DUST DEFLECTOR	1
195	153451-00	BEARING,THRUST	1
199	N390810	LOWER GUARD ASSY	1
200	N457634	LABEL,IDENT.	1
201	623788-00	WARNING LABEL	1
202	148608-00	INSERT	2
203	386780-00	BEARING	2
204	N027988	LOWER GUARD	1
205	N020822	GUARD PLATE	1
206	385915-01	SCREW	4
207	621037-00	PIVOT PLATE	1
208	146768-00	BUMPER	1
209	N142523	GUARD LINK	1
212	146750-01	RETAINING PLATE	1
213	N034013	TORSION SPRING	1
214	148295-00	SLEEVE,PIVOT	1
215	625825-00	ROLLER	2
216	142273-00	RING,RETAINING	2
217	394976-00	LABEL, CAUTION	2
218	146760-02	STUD	1
219	153666-00	SCREW,SET	2
220	656400-00	WARNING LABEL	2



## Parts List for DHS790AT2 Type 20

Item Number	Part Number	Description	Qty Required
221	N466081	WARNING LABEL	1
228	397117-00	WIPER	4
229	N049684	COVER PLATE	2
230	N455343	END CAP	1
231	N443949	TRUNNION	1
232	330019-14	SCREW	1
239	N126162	DUST BAG	1
240	N142123	CLAMP ASSEMBLY	1
314	N441566	STABILIZER BAR	1
315	N058319	RAIL	1
332	N104494	RAIL	1
333	N450867	BRACKET	1
533	N443880	SWITCH	1
534	N300152	RUBBER CAP	1
800	5140061-28	GREASE	1
800	93488-00	GREASE	1
856	DW7084	CROWN STOPS	1
856	DW7080	EXTENSION SYSTEM	1
856	DW3126	12IN. 60T SER.20 SAW BLD	1
857	DCA120	POWER PACK	1
866	DCB606	FLEXVOLT BATTERY	2
867	N475920	BATTERY CAP	1
871	DCB132	CHARGER	1